

PADDOCK CLEANER100/500 PARTS DIAGRAM

10/07



1A –FRAME 100 HAND & TOW	PAD 1006	13 – THROTTLE BRACKET	PAD1015
1B –FRAME 200 TOW TIPPING	PAD1007	14A –WHEEL 500	PAD400-8REDK358
2 – PLASTIC HOPPER	PAD1005	14B –WHEEL 500+	PAD16X6.50-4PRST50T
3 – HOSE 2.5M	PAD1034	15A – WASHER	PAD1027
4 – PICKUP NOZZLE	PAD1072	15B–SPLIT PIN	PAD1028
5 – CHAIN	PAD1050	17 – ENGINE FRAME	PAD1008LONG
6A –DOOR RETAINER FEMALE	PAD1067	18 –FILTER	PAD1017
6 B– DOOR RETAINER MALE	PAD1066	19 –FILTER BRACKET	PAD1018
7 – HOSE	PAD1029A	20 –LITTER FILTER	PAD1049
8A – SPIGOT FOR HOSE	PAD1039	21 –FILTER SOCK	PAD1049 SOCK
8B – SPONGE GASKET	PAD1043	22 – PLATE	PAD1026
9A –TOW BAR 3” RISE	PAD1012	23 –ENGINE UNIT	KRB400-B BLOWER
9B –TOW BAR 11” RISE	PAD1013	24 – AIR REDUCER GAUZE	PAD1016
9C –ANTI ROLE TOW BAR 3”	PAD1060	25 –SEAL	PAD1088
10 – SCRAPER PLATE BLOWE	PAD1073	26 – HOSE CLIP 125mm X2	F10182
11 – 50mm BALL HITCH	PAD1004	27A – CATCH FEMALE	PAD1070
12A–DROP PIN HITCH FOR 9A	PAD1014	2B – CATCH MALE HOOK	PAD1071
12B– DROP PIN HITCH FOR 9C	PAD1014S	---- FOOT PEDAL SPRING	PAD1075
		----ANTI STATIC WIRE	PAD1056